



MAGELAN MAIN WATER PROTECTOR

Data sheet

Brief description:

The main water protector is used for constant monitoring of the main water line. After the Magelan leakage sensors report a water intrusion or a leak, the main water pipe is closed immediately. A commercially available, electromotive ball valve (230V) is connected to the main water protector. In conjunction with Gateway GT-100.

Magelan Main Water Protector



Item number: MHP-3970

Properties

- For monitoring the main water pipe.
- Used with the Magelan leakage sensor.
- The Magelan siren can also be connected for acoustic warning.
- Any standard electromotive ball valve can be connected to the Magelan main water protector (230 V)
- Repeater for the blossom-ic system.
- In connection with the gateway GT-100.

Scope of application

Magelan Main Water Protector

Constant monitoring of the main water pipe. In conjunction with Gateway GT-100.

After the Magelan leakage sensors report a water ingress or a leak, the main water pipe is closed immediately. With the blossom-ic radio and app technology, the main water pipe can be closed and opened at any time, even from a distance.

A standard electromotive ball valve (230 V) is connected to the Magelan Main Water Protector.

Gateway GT-100

To control blossom-ic products via the Internet, simply and conveniently using the blossomic app. The blossomic app is available for all smartphones and tablets with iOS and Android.

Radio Frequency Communication

- blossom-ic RF: 2.4GHz, ISM Band, 16 channels
- Range: up to 50 m in buildings

Technical data

Technical data – Magelan Main Water Protector

• Ambient temperature	0 ~ 50°C
• Ambient humidity	90% (non-condensing)
• Mains voltage	230V AC / 50/60Hz
• Dimension	L86 x B86 x T44 (mm)
• Wireless frequency	2.4GHz, ISM Band, 16 channels
• Protection class	IP 30
• RF-Test	RED 2014/53/EU
• CE	Available
• RoHs	Available
• Type of antenna	PCB antenna

blossom-ic

 intelligent controls

blossom-ic GmbH & Co. KG

Oberer Buxheimer Weg 60, 87700 Memmingen, Germany

P: +49 8331-756 965 80 **E:** info@blossomic.de

W: www.blossomic.de